# DIP SWITCH SETTINGS

# DIP SWITCH NO.1 SETTINGS

#### 1. COIN SWITCH NO.1 SETTINGS

. 00.	111 0111	TON NO	. 1 021	111100	,	
SW	1	2	3	4	COIN	PLAY
0	OFF	OFF	OFF	OFF	- 1	-1
	NO				1	22
8	ÖFF	ON			-1	23
	NO				1.	71
	OFF	OFF	ON	OFF	1	245
	ON				1	
	OFF	ON	12-71-11		71	To Aller
	NO				- 2	24
	OFF	OFF	OFF	ON	2	-5-3
	ON				. 2	- 5
	OFF	ON			3	- 4
	ON				0,3	7
	OFF	OFF	ON	ON.	3	4.
	ON				7-1	1.
	OFF	ON			-1	:3
	ON				FREE	PLAY.

FREEPLAY: You can play games without roins.

# 2 COIN SWITCH NO 2 SETTINGS

4. 60	TH OUT	ich no	. L ULI	TIMUS	32	7 7
SW	5	6	- 7	8	COIN	PLAY
0	OFF	OFF	OFF	OFF	1	Jul
	ON				. 1	5-
	OFF	ON			1	-9-
	ON	10.3			1	• 1
	OFF	OFF	ON	OFF	1	5: -
1110	NO			4.5	->10	6
	OFF	ОИ			.1	7
	ON	53(1)			2	1
	OFF	OFF	OFF	DN	- 2	3
	ON	40011			2	5-
	OFF	ON		, Y	-3	-13
	NO				3	.2:
	OFF	OFF	ИО	ON	3	4
	ОИ	SEE.			4	-1
	OFF	NO		SIL S	4	3
	КО				. 10	I D

# DIP SWITCH NO. 2 SETTINGS

# 1. THE NUMBER OF PLAYER'S LIFE

SW	1	2	NUMBÉR:		
	OFF	OFF	2		
0	NO		3 227		
	OFF	ON	5 ***		
	ON		7		

## 2. THE NUMBER OF BULLET (PER RED ENERTY OR BULLET BELT CAPTUREED)

SW	3	NUMBER	
	OFF	5.0	
0	ON	6.0	

# - 3. BONUS LIFE

SW	4	5	BONUS LIFE
0	OFF	OFF	AT 50,000PTS, 200,000PTS, AND 400,000PTS
	ON		AT 70,000PTS, 250,000PTS, AND 500,000PTS
137	OFF	ON	AT 50,000PTS ONLY
	ON		AT 70,000PTS ONLY

## 4. DIFFICULTY OF THE GAME

SW	6	-7	DIFFICULTY
	OFF	OFF	EASY. 12
OON	ON		NORMAL
	OFF	ON	DIFFICULT
	ON		VERY DIFFICÜLT

#### 5. SOUND IN ATTRACTIVE MODE

SW	8	SOUND	
	OFF	OFF	
0	ON	ON	2-31//2

## DIP SWITCH NO.3 SETTINGS

# 1. VIDEO SCREEN FLIP

SW	1	
0	OFF	NORMAL
	ON	UPSIDE DOWN

# 2. CHANGE OF MODE

SW.	3	HODE
0	OFF	GAME MODE
	ON	TEST MODE

SW2 and SW4 are not used.

O shows recommended settings.

